正面(Front)

英文

背面(Back)

法文

296MM

630MM

Lenco

Portable boombox with DAB+/ FM radio, Bluetooth and CD player

SCD-860



INSTRUCTION MANUAL

For information and support, www.lenco.com

GB-1

WARNING

CLASS 1 LASER PRODUCT

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
PRODUCTO LÁSER DE CLASE 1

CAUTION
INVISIBLE LASER RADIATION
WHEN OPEN AVOID EXPOSURE TO BEAM
ATTENTION
AVOID EXPOSURE TO BEAM

This product contains a low power laser device.

Removal of the battery (if any)

Remove the battery before disposing of the device.

CAUTION

Usage of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

IMPORTANT SAFETY INSTRUCTIONS

READ THESE INSTRUCTIONS IN WHOLE:

1) Do not cover or block any ventilation openings. When placing the device on a shelf, leave 5 cm (2") free space around the device for ventilation.
2) Keep the device away from heat.
3) Place the device on a stable surface. Do not place the device on other equipment that may cause it to overheat. Avoid direct sunlight, naked flames and heat from other equipment that produces heat.
4) Do not place any sources of naked flames, such as lighted candles, on the device.
5) Avoid using the device near strong magnetic fields.
6) Avoid the ingress of liquids into the device and do not place any liquid containing objects, such as vases, on the device. Do not expose the device to dripping or splashing.
7) Only use the device in moderate climate. Extremely cold or severe weather conditions may adversely affect the device and batteries.
8) Do not use in a moist areas such as bathrooms, steamy kitchens or near swimming pools.
9) Only use the device in tropical climate if the device is specified for use in tropical climate. Avoid exposure to liquids, such as rain, sleet, and dew or in a moist the atmosphere.
10) Do not attempt to service the device yourself. Opening or removing covers may expose you to dangerous voltage or other hazards. Refer all repairs to qualified service personnel.
11) Do not use in a dusty environment.
12) To clean the device, use a soft dry cloth. Do not use solvents or petrol based fluids. To remove severe stains, you may use a cloth slightly moistened with water.
13) Do not place any sources potential for damage or risk take causes to malfunction, mouse, modification of the device or battery pack on the device.
14) Do not attempt the connection other the device is formatting or transferring files. Otherwise, data may be corrupted or not transferred properly. Lenco does not guarantee the compatibility with all USB devices and does not accept any liability for damaged or lost data due to incompatibility, defective devices and/or defective media and/or loss of the data.
15) Only use the device for playing back audio and storing data files. Lenco does not guarantee the correct operation of other equipment and knowledge, unless Lenco or other supplierset or have received instructions about the correct use of the device for a specific application or purpose, or for storage.
16) The product is intended for non professional use only and not for commercial or industrial use.
17) Do not use the device if the device or any accessory shows visible signs of damage. Do not use the device if the device vibrates or shows or by Lenco is Lenco or other accessory or the protection contained within the user manual will not be effective.
18) Do not remove the casing of the device.
19) Consult Lenco the device or other electrical equipment.
20) Do not allow children access to plastic bags.
21) Use only accessories specified by the manufacturer.
22) Note on disposing by qualified service personnel. Disposing is required when the device has been damaged in any way, such as the power supply cord is the plug, when liquid has been spilled or objects have fallen into the device, when the device has been exposed to rain or moisture, does not operate normally or has been dropped.
23) If the product is delivered with power cable or AC adapter, the mains socket must be installed near the equipment and must be easily accessible.
24) Mains voltage must be free from distortion, interruption, spikes, surges, sags, etc. Do not use a generator unless it is of a type that is designed to provide a clean mains voltage. Don't step on or pinch the power adapter. Be very careful, particularly near the plugs and the cable's exit point. Do not place the device on the power cable or other cables. Do not place the device on other equipment. Keep all cables and other objects with free power cable. Pay very seriously to your the instructions.
25) Unplug the device from the mains socket before cleaning. Use only a soft, dry cloth for cleaning.
The normal cooling fan should be installed near the equipment and must be easily accessible.
Ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths, curtains, etc.
Excessive heat can hinder proper ventilation and cause malfunction. Place the device in a well-ventilated area. Do not place the device near heat sources such as radiators or other devices that produce heat.
Always hold the plug when pulling it out of the mains socket. Do not pull the power cord. This can cause a short circuit. Do not make knots in the power cord or tie it together with other cables. Place all cables out of reach.
Place power cables so that stepped on or pinched, or damaged by sharp objects. Do not place any objects on the power cable.
Do not place the device in the immediate vicinity of other electronic devices, which may be affected by electromagnetic radiation.
Other electronic devices may also affect the device.
Other electronic devices can also be affected by the device. Place the device in a stable position.
Do not place the device on other equipment that may cause it to overheat.
Do not place any sources of naked flames, such as lighted candles, on the device.
Do not place any liquid containing objects, such as vases, on the device.
Do not place the device in the immediate vicinity of other electronic devices, which may be affected by electromagnetic radiation.
Other electronic devices may also affect the device.
Other electronic devices can also be affected by the device.