



1. Getting started:



2. batteries in the outdoor sensor:




! Placing the batteries into the outdoor sensor must be done **within 1 minute** after inserting the 1.5V C batteries into the clock. The outdoor sensor will then be linked directly with the clock.


If it takes longer before you place the batteries into the outdoor sensor, the sensor won't be linked with the clock and the 'OUT' read-out will remain empty.

In this case, remove both the batteries from the outdoor sensor and the C batteries from the clock and then re-insert all of them within one minute.

3. Time setup:



4. Day setup:



5. Date setup:

A Slide the switch to ON (up).


C Slide the switch to OFF when the correct date is displayed.

B You'll hear a small engine running and the date display will change.



6. Month setup:


Turn anti-clockwise (e.g. towards your body) to set the month.



7. First time use:

Slide the switch to ON (up) to turn on the clock.

Press to switch the display between degrees Celsius and degrees Fahrenheit.



Tips & remarks:

- The clock is suitable as both a desk model and a wall model. The rear of the clock is provided with key holes to attach it to the wall.
- Please keep in mind this clock doesn't show daylight saving time nor does it keep track of leap years. In this case, you'll need to manually adjust the time/date.
- However, the clock does keep track of the amount of days each month has.
- When setting the time, you must set the POWER switch to OFF to prevent the date from possibly jumping a day too far.
- The clock is only suitable for indoor use.
- Only clean the clock with a moist cloth. Never use any cleaning agents.



Specifications temperature sensor:

- Range indoor sensor: 0 to 50°C, range outdoor sensor: -40 to 70°C, accuracy: ±5%, distance clock-sensor: up to 25m.



Service   WWW.FYSIC.COM
SERVICE@FYSIC.NL **FYSIC**

Help   NL 073 6411 355 (Lokaal tarief)
BE 03 238 5666 (Lokaal tarief)
DE 0180 503 0085 (Lokale Festnetzkosten)

 Hesdo, Australiëlaan 1, 5232 BB,
's-Hertogenbosch, The Netherlands

Do not discard exhausted batteries, but bring them to your local depot for small chemical waste.

When this product has reached the end of its lifespan, it must not be discarded as regular domestic waste; you're obliged to take it to a collection point for the recycling of electric en electronic device.

